

Instructions for Using Equipment in Craig Lee

http://www.ric.edu/toolbox/building_information/index.htm

The equipment in this room is controlled by the Extron Control Panel, on the cabinet. If you need assistance with operating the system, please call the Help Center at 456-8803.



To turn on/off the Epson projector:

- 1) To turn on projector, push one of the source buttons (i.e. PC) on the Extron panel.
- 2) Once the Projector turns on, select the **Source** to project.
- 3) To turn off projector, push the **“DISPLAY OFF”** button on the Extron panel and press **“Power Off”**.

Extron Control Panel



Selecting equipment to be displayed through the Epson projector by the Extron Panel:



Computer - Boot the computer, and select **PC** on the Extron Panel.

Laptop - Hook laptop to the VGA or HDMI cable, and select **LAPTOP** and then press either **“VGA”**, **“HDMI”** or **“ShareLink”** on the Extron Panel.

Note: If the laptop is not projecting, You may need to send the image from your laptop. On the laptop, push both the “Fn” & “CRT/LCD” keys from the keyboard at the same time until you see the image from your laptop projected on the screen.

Blu-ray Player - Use the remote to turn on the player, and select **Blu-ray** on the Extron Panel.

Note: The blu-ray controls will automatically display on the Extron panel once the Blu-ray button has been pressed.



Mute/Project Display on the Extron Panel:

- 1) To mute the projection on the screen, push the **“ADVANCED”** button on the Extron panel and then select press **“MUTE”**. Press **“UNMUTE”** to turn the projector on again.